



Sensor Specification Summary

NO2-A1	NO2-AE	NO2-B1	NO2-D4
0 to 20	0 to 200	0 to 20	0 to 20
-400 to -750	-100 to -170	-600 to -1,150	-200 to -450
< 0.02	< 0.1	< 0.02	0.1
< 50	< 40	< 60	< 35
< ± 0.4	< ± 1.5	< ± 0.2	± 0.8
100	1,000	100	60
> 24	> 24	> 24	> 24
-20 to 50	-20 to 50	-20 to 50	-20 to 50
80 to 120	80 to 120	80 to 120	80 to 120
15 to 90	15 to 90	15 to 90	15 to 90
33	33	33	33

ent environments unless otherwise stated. As applications of use are outside our control, the responsibility. Customers should test under their own conditions, to ensure that the sensors

Alphasense sensors. Soldering, gluing or other methods of connection will void your warranty.